HUSSMAnn[®]



DDSS-4MC Medium Temperature Self Contained Open Vertical Merchandisers



DDSS-4MC

Installation & Operation Manual

IMPORTANT Keep in store for future reference!

P/N 0515957_N December 2018

> Spanish 0531283 French 0531284

HUSSMANN CORPORATION • BRIDGETON, MO 63044-2483 U.S.A.



IMPORTANT KEEP IN STORE FOR FUTURE REFERENCE Quality that sets industry standards!

12999 St. Charles Rock Road • Bridgeton, MO 63044-2483 U.S. & Canada 1-800-922-1919 • Mexico 01 800-890-2900 *www.hussmann.com* © 2018 Hussmann Corporation

TABLE OF CONTENTS

ANSI DEFINITIONS vi

INSTALLATION

UL Listing 1-1
Federal / State Regulation 1-1
Hussmann Product Control 1-1
Shipping Damage 1-1
Location
Model Description 1-3
Unloading 1-3
Exterior Loading 1-3
Shipping Skid 1-3
Merchandiser Leveling 1-4
Serial Plate Location 1-4
Refrigeration Unit Access 1-4
Casters 1-4
Sealing Merchandiser to Floor 1-4
Refrigeration Equipment Start
Up Check List 1-4

ELECTRICAL / REFRIGERATION

Merchandiser Electrical Data	2-1
Field Wiring	2-1
Electrical Connections	2-1
Electrical Outlet	2-1
Refrigeration (Self Contained)	2-1
Water Outlet and Water Seal	2-2

START UP / OPERATION

Controller Operation	3-1
Further Information	3-3
Connections	3-4
LED	3-4
KDE Plus Buttons	3-4
Setpoint	3-7
Sensor Location	3-8

Controls and Adjustments	3-10
Shelves	3-11
Load Limits	3-11
Stocking	3-11
Thermometer	3-12
Lighting	3-12
Night Cover	3-12

MAINTENANCE

Care and Cleaning	4-1
Do NOT Use	4-1
Do	4-1
Removing Scratches from Bumper	4-2
Cleaning Under Fan Plenum	4-2
Cleaning Stainless Steel Surfaces	4-2
Cleaning Discharge Honeycomb	4-3
Cleaning Coils	4-3
Cleaning Evaporation Pan	4-4
Maintaining Fluorescent Lamps	4-4

SERVICE

Replacing Fan Motors and Blades	5-1
Replacing Electronic Ballasts or	
LED Power Supplies	5-2
Replacing Fluorescent or LED Fixtures .	5-2

APPENDIX

Repairing Aluminum Coil	A-1
Part Numbers	A-2
Plan View DDSS-4MC	A-4
Cross Sections and Refrigeration Data	A-5
Defrost Data	A-5
Physical Data	A-5
Electrical Data	A-6
Self Contained Wiring Diagram	A- 7
Defrost Data Physical Data Electrical Data Self Contained Wiring Diagram	A-5 A-5 A-6 A-7

WARRANTY

REVISION HISTORY

REVISION N — Updated California Warning and ABS drain fitting

REVISION M — Page 3-8 removed sensor wire color

REVISION L — 1. Page 3-1 to 3-5-Removed previous controller information and replaced with new controller information 2. Page 3-6- Changed sensor colors Black to Green and Yellow to Orange - Replaced Sensors connections picture 3. Page 3-7-Replaced controller information 4. Page A-2-Removed selected components from part list and added parts 5. Page A-5-Removed thermostat setting selected information-On defrost termination change pressure (psig) to temperature (°F) 6. Page A-7-Replaced diagram with new revision

REVISION K — Revised for DOE

REVISION J — Updated Plug, Page 2-1 and A-7

REVISION H — Updated Wiring Diagram

REVISION G — Sensor Location, 3-6; Updated Coil photos, 3-8, parts list A-1, A-2 new Wiring Diagram, A-5 Replacing Fluorescent Lamps and Ballasts, 5-2

REVISION F — Added Checklists Page 1-7 and 1-8; Added Warning Page 1-3; Cleaning Coils 4-3; Maintaining Fluorescent Lights 4-4.

REVISION E - FEBRUARY 2012

- 1. Updated Wiring Diagrams
- 2. Updated Mexico phone number

REVISION D - JANUARY 2012

- 1. Removed DDSS-4 Model
- 2. Added new part numbers
- 3. Revised refrigeration data
- 4. Added LED replacement, Page 5-2

REVISION C - MAY 2011

1. Revised Cross Section Shelf Length, page A-4

REVISION B - OCTOBER 2010

- 1. Added self contained location drawings, page 1-2
- 2. Added Remote Line Sizing, Koolgas, page 2-2
- 3. Added Koolgas and Remote Refrigeration, page 2-9
- 4. Added TEV drawing and adjustment, page 3-8
- 5. Added Cleaning Precautions, page 4-4
- 6. Added dimension drawings & technical data, pages, A-1, A-2

ORIGINAL ISSUE - MARCH 2010

ANSI Z535.5 DEFINITIONS



• DANGER – Indicate[s] a hazardous situation which, if not avoided, will result in death or serious injury.



• WARNING – Indicate[s] a hazardous situation which, if not avoided, could result in death or serious injury.

• **CAUTION** – Indicate[s] a hazardous situation which, if not avoided, could result in minor or moderate injury.

• **NOTICE** – *Not related to personal injury* – Indicates[s] situations, which if not avoided, could result in damage to equipment.

P/N 0515957_N

INSTALLATION

UL LISTING

These merchandisers are manufactured to meet ANSI/ UL 471 standard requirements for safety. Proper installation is required to maintain the listing.

FEDERAL / STATE REGULATION

These merchandisers at the time they are manufactured, meet all federal and state/ provincial regulations. Proper installation is required to ensure these standards are maintained. Near the serial plate, each merchandiser carries a label identifying the environment for which the merchandiser was designed for use.

ANSI/NSF-7 Type I – Display Refrigerator / Freezer Intended for 75°F (24°C) / 55%RH Ambient Application

ANSI/NSF-7 Type II – Display Refrigerator / Freezer Intended for $80^{\circ}F$ / 55%RH Ambient Application

ANSI/NSF-7 – Display Refrigerator Intended for Bulk Produce

HUSSMANN PRODUCT CONTROL

The serial number and shipping date of all equipment is recorded in Hussmann's files for warranty and replacement part purposes. All correspondence pertaining to warranty or parts ordering must include the serial number of each piece of equipment involved. This is to ensure the customer is provided with the correct parts.

SHIPPING DAMAGE

All equipment should be thoroughly examined for shipping damage before and during unloading. This equipment has been carefully inspected at our factory. Any claim for loss or damage must be made to the carrier. The carrier will provide any necessary inspection reports and/or claim forms.

Apparent Loss or Damage

If there is an obvious loss or damage, it must be noted on the freight bill or express receipt and signed by the carrier's agent; otherwise, carrier may refuse claim.

Concealed Loss or Damage

When loss or damage is not apparent until after equipment is uncrated, retain all packing materials and submit a written response to the carrier for inspection within 15 days.

LOCATION

Recommended operating ambient temperature is between 65°F (18°C) to 80°F (26.7°C). Maximum relative humidity is 55%.

These merchandisers are designed for displaying products in air conditioned stores where temperature is maintained at or below the ANSI / NSF-7 specified level and relative humidity is maintained at or below 55%. Placing refrigerated merchandisers in direct sunlight, near hot tables or near other heat sources could impair their efficiency. Like other merchandisers, these merchandisers are sensitive to air disturbances. Air currents passing around merchandisers will seriously impair their operation. Do NOT allow air conditioning, electric fans, open doors or windows, etc. to create air currents around the merchandiser. Product should always be maintained at proper temperature. This means that from the time the product is received, through storage, preparation and display, the temperature of the product must be controlled to maximize the life of the product.

BE SURE TO POSITION SELF CONTAINED MERCHANDISERS PROPERLY.

SELF CONTAINED models have vented base panels to allow air circulation through the condensing unit. Allow for a minimum 4 in. clearance from walls, merchandisers, and any other large objects near the merchandiser's vented base panels (for self contained models). Blocking or restricting air flow will adversely affect performance and may damage the refrigeration system.



This warning does not mean that Hussmann products will cause cancer or reproductive harm, or is in violation of any product-safety standards or requirements. As clarified by the California State government, Proposition 65 can be considered more of a 'right to know' law than a pure product safety law. When used as designed, Hussmann believes that our products are not harmful. We provide the Proposition 65 warning to stay in compliance with California State law. It is your responsibility to provide accurate Proposition 65 warning labels to your customers when necessary. For more information on Proposition 65, please visit the California State government website.



MODEL DESCRIPTION

The DDSS models are open, vertical, medium temperature display merchandisers. Each self contained model will have its own condensing unit, factory installed beneath the display area of the case ready for operation when electrical service is connected.

UNLOADING

Unloading from Trailer:

Lever Bar (also known as a Mule, Johnson Bar, J-bar, Lever Dolly, or Pry Lever)

Move the merchandiser as close as possible to its permanent location and remove all packaging. Check for damage before discarding packaging. Remove all separately packed accessories such as kits and shelves.

Improper handling may cause damage to the merchandiser when unloading. To avoid damage:

1. Do not drag the merchandiser out of the trailer. Use a Johnson bar (mule).

2. Use a forklift or dolly to remove the merchandiser from the trailer.



Do NOT stand or walk on top of merchandiser. Do not store items or flammable materials atop the unit. **Do NOT walk on top of merchandisers** or damage to the merchandisers and serious personal injury could occur.

MERCHANDISERS ARE NOT STRUCTURALLY DESIGNED TO SUPPORT EXCESSIVE EXTERNAL LOADING such as the weight of a person. Do not place heavy objects on the merchandiser.

SHIPPING SKID

Each merchandiser is shipped on a skid to protect the merchandiser's base, and to make positioning the case easier.

Remove the top of the crate and detach walls from each other. Lift crate from the skid. Unscrew the case from the skid. The fixture can now be lifted off the crate skid. *Lift only at base of skid!* Remove any braces and/or skids attached (blanket wrapped merchandiser may have skids).

DO NOT LAY MERCHANDISER OVER ON THE FLOOR TO REMOVE SKID.

Once the skid is removed, the merchandiser must be lifted —NOT PUSHED— to reposition. To remove the skid, remove screws attaching skid to the merchandiser.

Check floor where cases are to be set to see if it is a level area. Determine the highest part of the floor.



Do NOT remove shipping crate until the merchandiser is positioned for installation.

1-4 INSTALLATION

MERCHANDISER LEVELING

BE SURE TO POSITION MERCHANDISERS PROPERLY. Level the merchandiser by all four corners. Merchandiser(s) must be installed level to ensure proper operation of the refrigeration system, and to ensure proper drainage of defrost water.

SERIAL PLATE LOCATION

The serial plate is located at the interior top left end. It contains all pertinent information such as model, serial number, amperage rating, refrigerant type and charge.

JUSSMAN

REFRIGERATION UNIT ACCESS

Serial Plate

The lower front panel may be removed by lifting the panel straight upward and over the tabs on which it is hanging. In a self contained merchandiser, two screws will have to be removed from either end of the panel. The panel is installed by reversing the above procedure. Ensure lower front panel is flat against the floor when installed to prevent air circulation problems on self contained merchandisers.



CASTERS

The merchandiser is equipped with optional casters. Use the brake to lock the merchandiser in place.



SEALING MERCHANDISER TO FLOOR

If required by local sanitary codes, or if the customer desires, merchandisers may be sealed to the floor using a vinyl cove base trim. The size needed will depend on how much variation there is in the floor, from one end of the merchandiser to the other. Sealing of the lower front and rear panels on self contained models may hamper their removal for servicing or maintenance of the condensing unit.

NOTE: Do not allow trim to cover any intake or discharge grilles located in the lower front panel.

Hussmann Self-Contained Refrigeration Equipment Start Up Check List

Please note that failure to follow this start-up document may void your factory warranty

Step	Startup Activity	Check
1	Locate, read and maintain install/operation manual in a safe place for future reference.	
2	Examine unit. Confirm there is NO damage or concealed damage.	
3	Level the unit, side to side and front to rear.	
4	Remove all shipping brackets/compressor straps/bolts etc.	
5	Unit must be run on a dedicated electrical circuit without the use of an extension cord.	
6	Ensure that the proper electrical requirements for the equipment are supplied.	
7	Verify field electrical connections are tight.	
8	Verify all electrical wiring is secured and clear of any sharp edges or hot lines.	
9	Verify the condensate drain line is properly trapped and pitched.	
10	Verify all required clearances on the sides and back of unit.	
11	Verify there are no air disturbances external to the unit. Heat and air registers, fans, and doors etc.	
Advise owner/operator that merchandiser must operate at temperature for 24 hrs prior to loading with product.		

Form HSCW01 Rev. 30MAY12 P/N 0525209_B

LEGAL DISCLAIMER:

Hussmann shall not be liable for any repair or replacements made without the written consent of Hussmann, or when the product is installed or operated in a manner contrary to the printed instructions covering installation and service which accompanied such product.

Hussmann Self-Contained Refrigeration Equipment Start Up Check List

Hussmann Corporation, 12999 St Charles Rock Road, Bridgeton, MO 63044-2483 U.S.A. Email: hussmannwarrantyregistration@hussmann.com Fax: 866-443-1254

Today's Date	
Store Name and Number	
Store Address	
Unit Model Number	
Unit Serial Number	
Contractor/Technician	
Startup activity	Record date of completion or requested data (i.e., voltage,
	measurements, instrument readings).
Locate, read and maintain install/operation manual in a safe place for future reference.	
Examine unit. Confirm there is NO damage or concealed damage.	
Level the unit, side to side and front to rear.	
Remove all shipping brackets/compressor straps/bolts etc.	
Unit must be run on a dedicated electrical circuit without the use of an extension cord.	
Record supply voltage at outlet with unit off.	Volts -
Verify refrigerant lines are properly secured and not touching or rubbing other lines, wires or frame work.	
Verify fan motors and motor mounts are tight.	
Verify fan blade/s are tight and are not rubbing/contacting other components.	
Verify field and factory electrical connections are tight.	
Verify electrical connections at lamps are tight and secure.	
Verify all electrical wiring is secured and clear of any sharp edges or hot lines.	
Verify there any no visible oil or refrigerant leaks.	
Verify the condensate drain line is properly trapped and pitched.	
What are the clearances on the sides and back of unit?	Left Side - Right Side - Back - Top -
Are there any air disturbances external to the unit? Heat and air registers, fans, and doors etc.	
Start up unit, record total unit amp draw after 5 minutes of operation.	Total unit amps -
Record compressor amp draw.	Amps -
Record anti-sweat heater amp draw if applicable	Amps - N/A
Record voltage reading with unit running.	Volts -
Verify condenser and evaporator fans are working	
Is condenser air inlet or air exhaust restricted or recirculating?	
Record ambient conditions around unit (wet Bulb temperature and dry bulb temperature) and RH%	Wet Bulb °F Dry Bulb °F RH%
Record condenser air inlet temp (center of the coil)	۴F
Record condenser air outlet temp (right after the fan motor)	°F
After unit reaches operating temperature, record unit discharge air temperature (enter of the flue).	°F
After unit reaches operating temperature, record unit return air temperature(center of flue).	°F
Does unit controller operate properly? See controller or I/O manual for proper controller operation.	
Record defrost heater amp draw (when applicable).	Amps -
Verify there are no visible water leaks.	
Verify door switches work correctly, turning evap fans on and off.	
Verify unit doors and lids work and are fully sealed.	
Verify that all the panels, shields and covers are in place.	
Confirm the unit has no vibrations or abnormal noise.	
Advise owner/operator that merchandiser must operate at temperature for 24 hrs prior to loading with product.	

Technician Notes:	

Form HSCW01 Rev. 30MAY12

P/N 0525209_B

LEGAL DISCLAIMER:

Hussmann shall not be liable for any repair or replacements made without the written consent of Hussmann, or when the product is installed or operated in a manner contrary to the printed instructions covering installation and service which accompanied such product.

ELECTRICAL / REFRIGERATION

MERCHANDISER ELECTRICAL DATA

Refer to merchandiser serial plate for electrical information.

FIELD WIRING

Field wiring must be sized for component amperes stamped on the serial plate. Actual ampere draw may be less than specified.

ALWAYS CHECK THE SERIAL PLATE FOR COMPONENT AMPERES

ELECTRICAL CONNECTIONS

All wiring must be in compliance with NEC and local codes. All electrical connections *(for remote models)* are to be made in the electrical *Handy Box* located behind the removable base panel at the left end of the merchandiser when facing the discharge honeycomb.

ELECTRICAL OUTLET

Before the merchandiser is connected to any wall circuit, use a voltmeter to check that the outlet is at 100% of the rated voltage. The wall circuit must be dedicated for the merchandiser. Failure to do so voids the warranty. **Do not use an extension cord.** Never plug in more than one merchandiser per electrical circuit.

- Always use a dedicated circuit with the amperage stated on the unit.
- Plug into an outlet designed for the plug.
- Do not overload the circuit
- Do not use long or thin extension cords. Never use adapters.
- If in doubt, call an electrician.

— LOCK OUT / TAG OUT — To avoid serious injury or death from electrical shock, always disconnect the electrical power at the main disconnect when servicing or replacing any electrical component. This includes, but is not limited to, such items as doors, lights, fans, heaters, and thermostats.



Self-contained models have factory-installed power cords attached at the electrical box.

REFRIGERATION (Self Contained Models)

Each self contained model is equipped with its own condensing unit and control panel located beneath the display area. The correct type of refrigerant will be stamped on each merchandiser's serial plate. The merchandiser refrigeration piping is leak tested. The unit is charged with refrigerant, and shipped from the factory with all service valves open.

Risk of Electric Shock. If cord or plug becomes damaged, replace only with a cord and plug of the same type.



Merchandiser must be grounded. Do not remove the power supply cord ground.

2-1

WATER OUTLET AND WATER SEAL

The condensate water outlet is located in the center of the merchandiser. The outlet has a factory installed, external water seal.

For self contained models, this water seal drains into the condensate evaporator pan located beneath the merchandiser.

For installation or maintenance of the P-TRAP, use only adhesive compatible with ABS fittings.



Item # 18s279

NOTE: All lower base panels must be in place when the refrigerator is operating. If not, airflow from the condenser will be directed over the evaporator pan and defrost water in the pan may overflow.

WARNING

Product will be degraded and may spoil if allowed to sit in a non-refrigerated area.

Refrigeration lines are under pressure. Refrigerant must be recovered before attempting any connection or repair.

WARNING

— LOCK OUT / TAG OUT —

To avoid serious injury or death from electrical shock, always disconnect the electrical power at the main disconnect when servicing or replacing any electrical component. This includes, but is not limited to, such items as doors, lights, fans, heaters, and thermostats.

A WARNING

Merchandiser must be grounded. Do not remove the power supply cord ground.

Risk of Electric Shock. If cord or plug becomes damaged, replace only with a cord and plug of the same type.

START UP / OPERATION

CONTROLLER OPERATION

The electronic controller is located in the cassette compartment. The controller comes factory set, and is ready for use. The front grille must be removed in order to access this control. When removing the grille for this operation or for condenser cleaning, care must be taken not to damage the display interface cable. It may be unplugged during this task.

1. Plug the merchandiser plug into its receptacle.

- a. The controller display will illuminate.
- b. The interior light will illuminate.

2. After the control preprogrammed time delay of up to 6 minutes, the compressor and evaporator fan(s) will start if the control is calling for cooling.

3. The control will cycle the compressor but may also cycle evaporator fan(s) on and off determined by the Set-Point and Differential temperatures.

- a. The Set-Point is the adjustable preprogrammed temperature.
- b. The Differential is the non-adjustable pre programmed temperature.
- c. The Control is designed to read and display a cabinet temperature not a product temperature.

KDEPLUS BUTTONS

The **KDEPlus** keyboard has 4 keys, as shown in the illustration:

This cabinet temperature may reflect the refrigeration cycle of the Set-Point and it's Differential. The most accurate temperature on a cabinets operation is to verify the product temperature.

Taking as an example a VRL case, freezer, If the Set-Point is -12° F and the Differential is 9° F. (Set-Point) -12° F + 9 (Differential) = -3° F. The compressor and evaporator fan(s) will cycle off -12° F and back on at -3° F.

Main Features:

• Panel-mounted

• Energy saving algorithms and optimised defrost control

- 8 preloaded applications
- Defrost at single / double evaporator
- Frame Heater
- Local network auto-configuration
- Direct load connection (up to 2 HP)
- Supply voltage control LVD
- Presence of an open collector output





DDSS Open Vertical Merchandisers

Key Functions:

- 2 ON/OFF regulators for HOT/COLD
- Single defrost and double evaporator
- (heatings, modulated heaters, reverse cycle, hot gas)
- Evaporator fans and condenser fans
- Frame Heater
- AUX
- Light
- Door switch
- ON /OFF
- Deep cooling cycle
- Day / Night
- Diagnostics
- "Easy Map" programming
- Programmable inputs/outputs
- LINK2 local area network
- RS485 communication protocol: Modbus
- Compatible with Device Manager (DM)
- Compatible with Unicard and Multi-function key

TECHNICAL DATA

Classification:	electronic automatic control (not safety) device for incorporation
Mounting:	panel mounting
Type of action:	1.B
Pollution class:	2
Material class:	Illa
Overvoltage category:	
Nominal pulse voltage:	2500V
Temperature:	Use: -5 +55°C - Storage: -30 +85°C
Power supply:	SMPS 100-240Va ±10% 50/60 Hz
Power consumption:	5.5W max
Fire resistance category:	D
Software class:	A
RTC battery life:	In absence of external power, the clock battery will last 3 years.

FURTHER INFORMATION

INPUT CHARACTERISTICS

Measurement	range:

Accuracy:

Resolution: Buzzer: Analogue/Digital Inputs: NTC: -50.0°C ... +110°C; PTC: -55.0°C ... +150°C; PT1000: -60.0°C ... +150°C (on 3-digit display with +/- sign) ±1.0° for temperatures below -30°C ±0.5° for temperatures between -30°C and +25°C ±1.0° for temperatures above +25°C 1 or 0.1°C NO 5 configurable NTC/PTC/PT1000/DI inputs 1 multi-function, voltage-free digital input (D.I.)

OUTPUT CHARACTERISTICS

Digital Outputs:	OUT1:	1 SPST relay:	2HP	max 240V~
	OUT2:	1 SPDT relay:	1HP	max 250V~
	OUT3:	1 SPDT relay:	8(4)A	max 250V~
	OUT4:	1 SPST relay:	8(4)A	max 250V~
OC (Open Collector) Output:	OC:	1 multifunctiona	l output:	12V 20mA

MECHANICAL CHARACTERISTICS

Dimensions: Terminals: Connectors: Humidity: 121x92 mm faston and screw for wires with cross-section of 2.5mm² TTL for Unicard / Device Manager connection (via DMI) Usage / Storage: 10...90% RH (non-condensing)

REGULATIONS

Electromagnetic compatibility: Safety: Food Safety: The device complies with Directive 2004/108/EC The device complies with Directive 2006/95/EC The device complies with standard EN13485 as follows:

- Suitable for storage.
- Application: air.
- Climate range A
- measurement class 1 in the range from -25°C to 15°C (*)
- (* with Eliwell probes only)

NOTE: The technical specifications stated in this document regarding measurement (range, accuracy, resolution, etc.) r the instrument alone and not to any accessories provided, such as the probes. This means, for example, that the error introduced by the probe must be added to the error of the instrument.

CONNECTIONS

TERMINALS



* **N.B.:** analogue inputs PB1...PB5 can also be configured as Digital Inputs DI.

TERMINALS				
1-2	NEUTRAL. These are power supply terminals.		15-16-17	Connection to KDEPlus or KDWPlus external keyboard or ECPlus echo module.
3	LINE. These are power supply terminals.		19-18	PB1 probe connection.
4	OUT2 Shared Terminal		21-20	PB2 probe connection.
5	N.O. OUT2		23-22	PB3 probe connection.
6	N.C. OUT2		23-24	PB4 probe connection.
7	OUT3 Shared Terminal		23-25	PB5 probe connection.
8	N.C. OUT3		27-26	Digital input (DI).
9	N.O. OUT3		28-29	LINK ² . Connection 1 - local area network.
10	OUT1 Shared Terminal		30-31	LINK ² . Connection 2 - local area network.
11	N.O. OUT1		32-33	Open Collector Output (OC).
12	Not Used		A	TTL Unicard/DMI/Multi Function Key connection
13	OUT4 Shared Terminal		34-35-36	RS485. Connection 1 - Supervision Gateway.
14	N.O. OUT4		37-38-39	RS485. Connection 2 - Supervision Gateway.

LED

RTN400 family controllers will also function even if a keyboard has not been connected. With **KDEPlus** or **KDWPlus** keyboards (which are the same and guarantee the same functions), the display will be as follows:



Meaning of LEDs:

No	lcon	LED	Operation	Meaning
			Permanently on	compressor on
1	1	Compressor	Blinking	Delay, protection or start-up blocked
			OFF	otherwise
			Permanently on	Defrost active
2		Defrost	Blinking	Activated manually or from Digital Input
			OFF	otherwise
2		Fanc	Permanently on	Fans active
3		rans	OFF	otherwise
			Permanently on	Energy Saving active
4	4 Reduced SET / Economy	Reduced SET / Economy	Blinking	Reduced setpoint active
		OFF	otherwise	
			Permanently on	alarm active
5	((ullet))	Alarm	Blinking	Alarm acknowledged
			OFF	otherwise
6	0	°E roadout	Permanently on	°F setting (dro =1)
0		Fleadout	OFF	otherwise
			Permanently on	Aux output active and/or light on
7	AUX	AUX	Blinking	Deep cooling on
			OFF	otherwise
0	°	°C readout	Permanently on	°C setting (dro = 0)
0	J	Creation	OFF	otherwise

N.B.: When the instrument is powered on it performs a lamp test, during which time the display and LEDs will flash for several seconds to check that they all function correctly.

KDEPLUS BUTTONS

The **KDEPlus** keyboard has 4 keys, as shown in the illustration:



Each key has a different function depending on whether it is:

- Pressed and released
- Pressed for at least 5 seconds
- Pressed and held at start-up
- Pressed in combination with another key.

KEYS

The following table summarizes the function of each key:

Nia	Kan	Action				
OVI	Кеу	Pressed and released	Press for at least 5 secs	Start-up		
1	~	Scrolls through menu itemsDecreases values	Activates the Manual Defrost function (from outside menus).			
2	*	Scrolls through menu itemsDecreases values	Function can be configured by the user (from outside menus). (see parameter H32)			
3	0	 Returns to the previous menu level Confirms parameter value 	Activates the Stand-by function (from outside menus).			
4	set	 Displays any alarms (if active) Opens Machine Status menu Confirms commands 	Opens the Programming Menu (User and Installer parameters)	When pressed during start-up it enables the user to select the application to be loaded.		

P/N 0515957_N

SETPOINT: SETTING AND EDIT LOCK

To display the Setpoint value, press the set key to enter the "Machine Status" menu, then press the set key again when the "SEt" label is displayed.

The Setpoint value appears on the display. To change the Setpoint value, press the 🕿 and 📚 keys within 15 seconds. Press set to confirm the modification.



It is possible to disable the keypad on this device.

The keypad can be locked by programming the "LOC" parameter appropriately.

With the keypad locked, you can still access the "Machine Status" menu by pressing set to display the Setpoint, but you cannot edit it. To disable the keypad lock, repeat the locking procedure.

DISPLAY PROBES VALUE

To display the value read by probes connected to the device, press the set key and enter the "Machine Status" menu, then press the key again when one of the probe-related labels "Pb1...Pb5" press the set key again. The value measured by the associated probe will appear on the display.

NOTE: The displayed value is read-only and cannot be modified.

KDEPLUS BUTTONS

The **KDEPlus** keyboard has 4 keys, as shown in the illustration:



KEY-ACTIVATED FUNCTIONS

All models have the **UP** key set to enable the "Manual Defrost" function. The DOWN and ESC keys can also be set to activate any other function required by the user. The parameters for configuring the two keys are:

- **H11** = DOWN key configuration
- **H33** = ESC key configuration

The values that can be set apply to both keys and the functions that can be activated are:

H32/H33 value	Function to enable
0	disabled
1	defrost
2	reduced set
3	Light
4	Energy saving
5	AUX
6	Stand-by
7	Deep cooling cycle
8	Start/end defrost

Sensor to Control Configuration







Suction Line

Orange Defrost Sensor is placed next to Tee, Reducing W-4014



	Refrigeratior Controls	ו		Defrost C	Controls	
Model	Product Application	Discharge Air Temperature	Defrost Frequency (per day)	Type of Defrost	Termination Temperature	Failsafe Time (Minutes)
DDSS-4MC	Medium Temp. (Dairy, Deli)	24° F to 32° F	4	Off Time	45° F	40

CONTROLS and ADJUSTMENTS

1. The Controller controls refrigeration temperature. This is factory installed in the control panel. Adjust this control knob to maintain the discharge air temperature shown. Measure discharge air temperatures at the center of the honeycomb. Defrosts are time initiated and temperature terminated for self contained and remote, including Koolgas models. The defrost setting is factory set as shown above.

To ensure a thorough defrost, defrost must be terminated by the temperature termination setting — not by time.

THERMOSTATIC EXPANSION VALVE (TEV)

Each self contained merchandiser has its own evaporator coil and a **pre-set** thermostatic expansion valve (TEV). The TEV has been factory set at design conditions to provide the recommended performance.

TEV Adjustment

Expansion valves may be adjusted to fully feed the evaporator. Before attempting to adjust valves, make sure the evaporator is clear or only lightly covered with frost, and the merchandiser is within 10°F of its expected operating temperature. Adjust the valve as Follows:

a. Attach a probe to the suction line near the expansion valve bulb.

b. Obtain a pressure reading from the factory installed Schraeder valve. Convert the pressure reading to a saturated temperature for the refrigerant.

Temperature (b) minus Temperature (a) is the superheat. The valve should be adjusted so that the greatest difference between the two temperatures is 3°F to 5° F.

Make adjustments of no more than 1/2 turn of the valve stem at a time and wait for at least 15 minutes before rechecking the probe temperature and making further adjustments.



LOAD LIMITS

Each merchandiser has a load limit decal. Shelf life of perishables will be short if load limit is violated.

AT NO TIME SHOULD MERCHANDISERS BE STOCKED BEYOND THE LOAD LIMITS INDICATED.

DO NOT BLOCK HONEYCOMB.

Product will be degraded and may spoil if allowed to sit in a non-refrigerated area.

THERMOMETER

DDSS models have a thermometer. The thermometer is located at the top, interior of the merchandiser.

LOAD LIMIT

STOCKING

Product should NOT be placed inside the merchandisers until merchandisers are at proper operating temperature.

Allow merchandiser 24 hours to operate before loading product.

Proper rotation of product during stocking is necessary to prevent product loss. Always bring the oldest product to the front and set the newest to the back.

AIR DISCHARGE AND RETURN FLUES MUST REMAIN OPEN AND FREE OF OBSTRUCTION AT ALL TIMES to provide proper refrigeration and air curtain performance. Do not allow product, packages, signs, etc. to block these grilles. Do not use non-approved shelving, baskets, display racks, or any accessory that could hamper air curtain performance.

Do not allow product to be placed outside of the designated load limits in the illustration.



3-12 START UP / OPERATION

NOTES:

MAINTENANCE

CARE AND CLEANING

Long life and satisfactory performance of any equipment is dependent upon the care it receives. To ensure long life, proper sanitation and minimum maintenance costs, these merchandisers should be thoroughly cleaned, all debris removed and the interiors washed down, weekly.

Exterior Surfaces

The exterior surfaces must be cleaned with a mild detergent and warm water to protect and maintain their attractive finish. NEVER USE ABRASIVE CLEANSERS OR SCOURING PADS.

Interior Surfaces

The interior surfaces may be cleaned with most domestic detergents, ammonia based cleaners and sanitizing solutions with no harm to the surface. Self contained models empty into a limited capacity evaporation pan, which will overflow if excess water is used in cleaning.

Do NOT Use:

•Abrasive cleansers and scouring pads, as these will mar the finish.

•Coarse paper towels on coated glass.

•Ammonia-based cleaners on acrylic parts.

•Solvent, oil or acidic based cleaners on any interior surfaces.

•Do not use high pressure water hoses.



Do:

•Remove the product and all loose debris to avoid clogging the waste outlet.

•Store product in a refrigerated area such as a cooler. Remove only as much product as can be taken to the cooler in a timely manner.

•Disconnect electrical power before cleaning.

•Thoroughly clean all surfaces with soap and hot water. **Do NOT USE STEAM OR HIGH WATER PRESSURE HOSES TO WASH THE INTERIOR.** THESE WILL DESTROY THE MERCHANDISERS' SEALING CAUSING LEAKS AND POOR PERFORMANCE.

•Take care to minimize direct contact between fan motors and cleaning or rinse water.
•Do NOT flood merchandiser with water.
NEVER INTRODUCE WATER FASTER THAN THE WASTE OUTLET CAN REMOVE IT.



Do NOT allow cleaning agent or cloth to contact food product.

SELF CONTAINED MODELS EMPTY INTO A CONDENSATE EVAPORATION PAN THAT WILL OVERFLOW IF TOO MUCH WATER IS INTRODUCED DURING CLEANING.

•Allow merchandisers to dry before resuming operation.

•After cleaning is completed, turn on power to the merchandiser.

WARNING

Do NOT use HOT water on Cold glass Surfaces. This can cause the glass to shatter and could result in personal injury. Allow glass fronts, to warm before applying hot water.

REMOVING SCRATCHES FROM BUMPER

Most scratches and dings can be removed using the following procedure.

- 1. Use steel wool to smooth out the surface area of the bumper.
- 2. Clean area.
- 3. Apply vinyl or car wax and polish surface for a smooth glossy finish.

CLEANING UNDER FAN PLENUM

To facilitate cleaning, the fan plenum is hinged.

After cleaning be sure the plenum is properly lowered into position OR PRODUCT LOSS WILL RESULT due to improper refrigeration.



— LOCK OUT / TAG OUT —

To avoid serious injury or death from electrical shock, always disconnect the electrical power at the main disconnect when servicing or replacing any electrical component. This includes, but is not limited to, such items as doors, lights, fans, heaters, and thermostats.

WARNING

SHUT FANS OFF DURING CLEANING PROCESS.



DO NOT FLOOD!

Use only enough water necessary to clean surface. Water must not drip down the case!

Never use ammonia based cleansers, abrasive cleansers, or scouring pads.

CLEANING STAINLESS STEEL SURFACES

Use non-abrasive cleaning materials, and always polish with grain of the steel. Use warm water or add a mild detergent to the water and apply with a cloth. Always wipe rails dry after wetting.

Use alkaline chlorinated or non-chlorine containing cleaners such as window cleaners and mild detergents. Do not use cleaners containing salts as this may cause pitting and rusting of the stainless steel finish. Do not use bleach.

CLEANING DISCHARGE HONEYCOMB

Discharge air honeycomb should be cleaned every six months. Dirty honeycomb will cause merchandisers to perform poorly. The honeycomb may be cleaned with a vacuum cleaner. Soap and water may be used if all water is removed from the honeycomb cells before replacing. Be careful not to damage the honeycomb.

- 1. Using a flat object such as a screw driver, behind the rear edge of the honeycomb on on the right hand end, and gently pull down.
- 2. Clean with a mild detergent and warm water and dry the honeycomb.
- 3. After cleaning, replace in reverse order. Damaged honeycomb must be replaced.



1. Installed Location



CLEANING COILS

Condenser coils should be cleaned at least once per month. Additional cleaning may be needed depending on the operational environment. A dirty condenser blocks normal airflow through the coils.



Airflow blockage increases energy consumption and reduces the merchandiser's ability to maintain operating temperature.

To clean the coils, use a vacuum cleaner with a wand attachment and a soft (non-metallic) brush to remove dirt and debris. Do not bend coil fins. Always wear gloves and protective eye wear when cleaning near sharp coil fins and dust particles.



CLEANING EVAPORATION PAN

The condensate water outlet empties into a limited capacity evaporation pan.

Debris or dirt accumulation inside the condensate evaporation pan or on the heater coil will reduce the pan's evaporation capacity and cause premature heater failure. The evaporation pan waste water will overflow and spill onto the floor if the heater is not properly operating.

Remove accumulated debris from the evaporation pan. Wipe down heater coil with a cloth and warm water. Be sure to remove any dirt, debris or liquids from the heater coil.

Water introduced during cleaning will cause the evaporation pan to overflow.

NEVER USE SHARP OBJECTS AROUND COILS. Use a soft brush or vacuum brush to clean debris from coils. Do not puncture coils! Do not bend fins. Contact an authorized service technician if a coil is punctured, cracked, or otherwise damaged.

ICE in or on the coil indicates the refrigeration and defrost cycle is not operating properly. Contact an authorized service technician to determine the cause of icing, and to make adjustments as necessary. To maintain product integrity, move all product to a cooler until the unit has returned to normal operating temperatures.



Evaporation Pan is Hot!

and poses risk of bodily injury — Always Wear gloves and protective eye wear when servicing. Turn off evaporation pan heater, and allow pan to cool.

MAINTAINING FLUORESCENT LAMPS (IF APPLICABLE)

Many of the self-contained cases are equipped with LEDs. For cases with fluorescent lamps, follow these directions to ensure long-lasting life of the lights:

Fluorescent lamps should not be allowed to run to failure. If a re-lamp schedule is not in place, the tubes should be inspected for signs of degradation (blackened ends). Degraded or failed tubes should be replaced.

Allowing severely degraded lamps to operate may cause a ballast failure or could expose the lamp holder to excessive heat. Replacing degraded bulbs is more cost effective than replacing ballast and lamp-holders. Traditional re-lamp programs are 18-to-24 month intervals. In the absence of a re-lamp program, a yearly inspection of the lighting system is recommended.

1. Inspect all lamp sockets and plug-receptacle connections for signs of arching. Replace any component that shows signs of arching.

2. Make sure all unused receptacles have their close-off covers securely installed.

3. Make sure proper cleaning procedures are followed. Lights and fans MUST be turned off when a case is cleaned and MUST be allowed to dry before turning power back on.

4. Do not use a pressure nozzle to clean inside of case.

SERVICE

REPLACING FAN MOTORS AND BLADES

Should it ever be necessary to service or replace the fan motors or blades be certain that the fan blades are reinstalled correctly. THE BLADES MUST BE INSTALLED WITH RAISED EMBOSSING (PART NUMBER ON PLASTIC BLADES) POSITIONED AS INDICATED ON THE PARTS LIST.

For access to these fans:

- 1. Remove product and place in a refrigerated area. Turn off power to the merchandiser.
- 2. Remove bottom display pans.
- 3. Disconnect fan from wiring harness.
- 4. Remove fan blade.
- 5. Lift fan plenum and remove screws holding bottom of motor to fan basket.
- 6. Replace fan motor and blade.
- 7. Lower fan plenum.
- 8. Reconnect fan to wiring harness.
- 9. Turn on power.
- 10. Verify that motor is working and blade is turning in the correct direction.



A WARNING

— LOCK OUT / TAG OUT — To avoid serious injury or death from electrical shock, always disconnect the electrical power at the main disconnect when servicing or replacing any electrical component. This includes, but is not limited to, such items as doors, lights, fans, heaters, and thermostats.

- 11. Close air gaps under fan plenum. Warmer air moving into refrigerated air reduces effective cooling. If the plenum does not rest against the case bottom without gaps, apply foam tape to the bottom of the fan plenum to reduce improper air movement. Use silicone sealant to close other gaps.
- 12. Reinstall display pans. Bring merchandiser to operating temperature before restocking.



DDSS Open Vertical Merchandisers

5-2 SERVICE

REPLACING ELECTRONIC BALLASTS OR LED POWER SUPPLIES

The canopy ballast or LED power supply is located in the electrical box on top of the merchandiser.

To gain access:

- 1. **DISCONNECT THE ELECTRICAL POWER TO** THE MERCHANDISER.
- 2. Remove top panel by removing the screws on top of the case.



REPLACING FLUORESCENT LAMPS OR LED FIXTURES

The lamp is removed as shown in the image below. The lamp twists out of its end cap.

The lamp can be replaced without removing the top panel.



3. The ballast is located under the top sign.



WARNING

Fluorescent lamps contain mercury vapor. Mercury exposure at high levels can harm the brain, heart, kidneys, lungs, and immune system of people of all ages. Do not break or puncture fluorescent lamps. Dispose of, or store, all fluorescent lamps in accordance with Federal (40 CFR 273), State, and local hazardous waste requirements. Refer to http://www.epa.gov/mercury/about.htm

P/N 0515957_N

REPAIRING ALUMINUM COIL

The aluminum coils used in Hussmann merchandisers may be easily repaired in the field. Materials are available from local refrigeration wholesalers.

NOTE:

Hussmann Aluminum melts	at1125°F	$(607^{\circ}C)$
Aladdin 3-in-1 rod at	732°F	(389°C)
X-Ergon Acid core at	455°F	(235°C)

Technique:

- 1. Locate Leak.
- 2. REMOVE ALL PRESSURE.
- 3. Brush area UNDER HEAT.
- 4. Use PRESTOLITE TORCH ONLY.

Number 6 tip.

- 5. Maintain separate set of stainless steel brushes, and USE ONLY ON ALUMINUM.
- 6. Tin surface around area.
- 7. Brush tinned surface UNDER HEAT, thoroughly filling the open pores around leak.
- 8. Repair leak. Let aluminum melt solder, NOT the torch.
- 9. Don't repair for looks. Go for thickness.
- 10. Perform a leak check.
- 11. Wash with water.
- 12. Cover with a good flexible sealant.

5-3

5-4 SERVICE

NOTES:

Models		DDSS4-MC
Standard Parts		
Description	Part Number	
LH End (Solid) Standard	0512892	Х
RH End (Solid) Standard	0512895	Х
LH View End	0513316	Х
RH View End	0513221	Х
End Acrylic (View end)	0512737	Х
Front Bumper (Black)	0512899	Х
Evap Fan Harness Main Feed	0376608	Х
Evap Fan Harness	0376609	Х
Air Sensor (Black) 4000MM	0510533	Х
Defrost Sensor (Yellow) 4000MM	0510532	Х
Safe-Net III Controller 65C	0524122	Х
Safe-Net III Display (F°) 65C	1H59052001	Х
Safe-Net III Display Interface Cable (1M)	0509783	Х
Safe-Net III Control Harness	0513058	Х
Condensate pan heater relay SPDT NC 208V	0342599002	Х
Compressor Relay (T92P7A22-240)	1804241	Х
Power Switch	03\$422	Х
Caster	355088	Х
Honeycomb	29\$866	Х
Power Cord NEMA 6-20P	1804385	Х
Fluorescent light (Canopy) F32T8	06S214	Х
Safety Shield for Fluorescent light (Canopy)	06S07414	Х
Ballast	06S187	Х
LED Power Supply (optional)	0518898	Х
LED Light (optional)	0515965	Х
Lamp Holder	06S248	Х
Light Switch	03S176	Х
Flue Glass	29\$863	Х
Sign Panel (acrylic)	29\$8731	Х
Glass Shelf 13" complete	0513065	Х
Glass for Shelf 13"	0513062	Х
Glass Shelf 10" complete	145996	Х
Glass for Shelf 10"	29\$870	Х

	DDSS4-MC
Part Number	
0511124	Х
E110101001	Х
2100226	Х
17\$507	Х
7408727	Х
0500354	Х
03\$558	Х
05S625	Х
0511147	Х
0511121	Х
26S138	Х
17\$579	Х
0515679	Х
0523011	Х
014278002	Х
	Part Number 0511124 E110101001 2100226 175507 7408727 0500354 03S558 05S625 0511121 26S138 17S579 0515679 0523011 014278002

Condensate Pan		DDSS4-MC
Description	Part Number	
Electric Condensate Pan Assy (w/heater & float switch)	1H11037001	Х
Condensate Pan Heater (750w)	1H07734001	Х
Float Switch	1804342	Х

Sheet Metal Replacement Parts Painted		DDSS4-MC
Description	Part Number	
Front Access Panel	0511144	Х
Panel Top Sign	144711	Х
Return Air Grille (Stainless Steel)	146721	Х
Bottom Shelf	0511142	Х
LH End Panel -Base	0511148	Х
RH End Panel -Base	0511145	Х
Metal Shelf 10" X 4' (optional)	22\$3021	Х
Metal Shelf 12" X 4' (optional)	2253022	X

All these part numbers below are painted assemblies

DDSS-4MC



General

Case Length (Note: Includes One Pair Ends)	4ft (51) (1295)
Maximum O/S dimension of case back to front	30 1/2 (775)
(Note: Includes bumper)	

Waste Outlet

RH end of case (from outside of End Assembly)	25 ¹ / ₂ (648)
to center of waste outlet	



Dimensions shown as inches and (mm).

REFRIGERATION DATA

Note: This data is based on store temperature and humidity that does not exceed 80°F and 55% R.H. unless otherwise stated. Schedule defrost at night while lights are off.

DDSS-4MC

Condensing Unit (hp) 1

Condensing UnitCapacity9992(Btu/hr at std. rating
conditions)

DEFROST DATA

Frequency (hr) 6

OFFTIME Failsafe (minutes) 40

Defrost TerminationTemperature45°F (7.2°C)

PHYSICAL DATA

Refrigerant Charge

DDSS-4MC 44 oz 1.248 kg

APPENDIX A — TECHNICAL DATA

Electrical Data

Note: These are rated values for individual components and should not be added together to determine total merchandiser electrical load.

Self_Contained

DDSS-4MC

Number of Fans – 12W

1		
T		

Remote

		Sen-Containeu		Kennote	
Evaporator Fans	Amperes	Watts	Amperes	Watts	
230V 60Hz Standard 0.33	0.33	50	0.12	18	
Condensate Pan Heaters (230V)	3.8	750	3.8	750	
Condensing Unit (208/230V, 1Ph, 6	60Hz) Standard	— Self-Contair	ied		
Compressor LRA			33.7		
Compressor RLA			6.8		
Minimum Circuit Ampacity — Self	f-Contained				
230V 1Ph 60Hz	Standard		10.85		
230V 1Рн 60Нz	Energy Efficient		10.67		
Maximum Over Circuit Protection	208/230V — Se	lf-Contained	20		
Maximum Circuit Ampacity — Re 230V 1Ph 60Hz Maximum Over Circuit Protection	mote Standard 208/230V — Re	emote	4.65 15		
DDSS-4 / DDSS4MC AHRI Total Display Area ¹ (Sq ¹ Computed using AHRI 1200 st Total Display Area, ft ² [m ²] / Un	Ft/Case) andard methodo it of Length, ft	ology: [m]	13.01 ft ² /case	(1.21 m ² /case)	
EST	IMATED SHIP	PING WEIGH	T ²		
Case					
Se	elf Contained	with Shipp	ing Crate	End	
lb (<i>kg</i>) 5	547 (248kg)	659 (299kg) Incl		Included	

Actual weights will vary according to optional kits included.

DDSS Open Vertical Merchandisers

DDSS-4MC — Self Contained

