

Shelf Installation

30 x 67 Innovator Door





BEFORE YOU BEGIN
Read these instructions completely and carefully.



PERSONAL PROTECTION EQUIPMENT (PPE)

Personal Protection Equipment (PPE) is required whenever servicing this equipment. Always wear safety glasses, gloves, protective boots or shoes, long pants, and a long-sleeve shirt when handling glass, or heavy metal objects such as shelving. Do not climb or stand on shelves.



IMPORTANT
KEEP IN STORE FOR FUTURE REFERENCE
Quality that sets industry standards!

12999 St. Charles Rock Road • Bridgeton, MO 63044-2483

U.S. & Canada 1-800-922-1919 • Mexico 01-800-890-2900

www.hussmann.com

© 2018 Hussmann Corporation




This warning does not mean that Hussmann products will cause cancer or reproductive harm, or is in violation of any product-safety standards or requirements. As clarified by the California State government, Proposition 65 can be considered more of a 'right to know' law than a pure product safety law. When used as designed, Hussmann believes that our products are not harmful. We provide the Proposition 65 warning to stay in compliance with California State law. It is your responsibility to provide accurate Proposition 65 warning labels to your customers when necessary. For more information on Proposition 65, please visit the California State government website.



INSTRUCTION FOR BRACKETS INSTALATION 30 x 67 INNOVATOR DOOR

Locate the holes on the rib of the top raceway.
(Two holes located above the light fixture).

Localiza los agujeros en la costilla de la parte superior del raceway. (Dos agujeros localizados encima de las lamparas)



The bracket should be fastened to the pre-drilled holes
Of the raceway , located above the light fixture

El bracket tiene que ser localizado en los agujeros pre-taladrados del raceway, localizados en la parte superior de las lamparas.



P/N 0209348

Fasten the "short Z" bracket with SCREW SM
SLFDRIL 8-18X1/2 .


El bracket "short Z" tiene que ser puesto con tornillo
SM SLDRIL 8-18X12.



Bracket fasten in the top raceway

Bracket localizado en la parte superior
del raceway.






Remove de cover to install the bracket. If you want changes the exit of the connector see page 7/7.

Remueve el cover para instalar el bracket. Si quieres cambiar la salida del conector ver pagina 7/7.




If you have a **frame of 2 and/or 3 doors** install the bracket in this way.

Si tu tienes un **marco de 2 y/o 3 puertas** instala el bracket en esta forma.



If you have a **frame of 4 and/or 5 doors** install the bracket how show.


Si tu tienes un **marco de 4 y/o 5 puertas** instala el bracket como se muestra.



Now install the cover again.

Ahora instala el cover o nuevo.

N/P 0209658



N/P 0209659

NOTE: All these installers are with screw 8 x 3/8".

NOTA: Todas estas instalaciones son con tornillo 8 x 3/8".


IMPORTANT: The “Short Z” brackets and the “Bracket upleft Lh 67” have to be installed as it is shown in the figure below.

IMPORTANTE: El bracket “Short Z” y el “Bracket upleft Lh 67” tienen que ser instalados como se muestra en la figura de abajo.




**FRAME WITH “SHORT Z” BRACKETS (UPPER) AND
THE BRACKET UPLEFT Lh 67.**

**MARCO CON BRACKET “SHORT Z” (SUPERIOR) Y EL
BRACKET UPLEFT Lh 67**



P/N 0208363



Locate and mark to drill at the bottom of each post of the frame to fasten the "big Z" bracket .


Localiza y marca para barrenar en la parte inferior de cada poste de el marco para fijar el bracket "big Z".

Fasten the "big Z" bracket with .125 pop rivets.


Fija el bracket "big Z" con remaches pop .125

IMPORTANT: The "Big Z" holder have to be locate as it is shown in the figure below.


IMPORTANTE: El bracket "Big Z" tiene que estar fijado en la localizacion como se muestra en la figura de abajo.



**FRAME WITH "BIG Z" BRACKETS (LOWER)
MARCO CON BRACKETS "BIG Z" (INFERIOR)**



1. Insert the post holder as shown in the picture above.
2. Insert the "Z" holder into the post holder.
3. Secure the post holder to the post using (2) 8-18 x 1/2" screws.
4. Repeat this in each post of the frame.



P/N 0208362-

1. Inserta el retenes del poste como se muestra en la figura superior izquierda.
2. Inserta el bracket "Z" dentro del reten del poste.
3. Fije el soporte del poste al poste utilizando (2) tornillos de 8-18 x 1/2 "
4. Repite esto en cada poste del marco.



P/N 0208362-



1. Insert the post holder as shown in the picture above.
2. Insert the "Z" holder into the post holder.
3. Secure the post holder to the post using (2) 8-18 x 1/2" screws.
4. Repeat this in each post of the frame.



1. Inserta los retenes del poste como se muestra en la figura superior izquierda.
2. Inserta el bracket "Z" dentro del retenel poste.
3. Fije el soporte del poste al poste utilizando (2) tornillos de 8-18 x 1/2 "
4. Repite esto en cada poste del marco.




**FRAME WITH
BRACKETS AND POSTS**

**MARCO CON
BRACKETS Y POSTES**

OPTION TO CHANGES THE EXIT OF THE CONNECTOR

1



If you want change the connector, remove the cover and unscrew the connector.

Si tu quieres cambiar el conector, remueve el cover y desatornilla el conector.

2



Then remove the plug and install it in the hole where you remove the connector.

Despues remueve el plug e instalalo en el agujero donde removiste el conector.

3



Install the connector and the conduit in the new location that you want.

Instala el conector y el conduit en la nueva localizacion que tu quieres.

4



Screw the connector, and install the cover again as show below.

Atornilla el conector, e instala el cover de nuevo como se muestra abajo.

5



NOTE: YOU CAN INSTALL THE CONECTOR IN THE DIFFERENTES FACES OF THE COVER FOLLOW THESE STEPS IN ORDER OF YOUR NEEDES.

NOTA: TU PUEDES INSTALAR EL CONECTOR EN LAS DIFERENTES CARAS DEL COVER SIGUIENDO ESTOS PASOS DE ACUERDO A TUS NECESIDADES.

HUSSmann®

**To obtain warranty information
or other support, contact your
Hussmann representative.
Please include the model and
serial number of the product.**

Hussmann Corporation, Corporate Headquarters: Bridgeton, Missouri, U.S.A. 63044-2483 01 October 2012