

PART NOS.	DESCRIPTION	UMM 1-BS	UMM 2-BS	UMM 3-BS	UMM 1-TS	UMM 2-TS	UMM 3-TS	NOTES
02s119	Compressor 3/4 hp 115-V R-12			1			1	Used Prior to S/N 94A00094 & Below
02s129	Compressor 1/2 hp 115-V R-12		1			1		Used Prior to S/N 94A00094 & Below
02s220	Condensing Unit 1/3 hp 115-V R-12	1			1			Used Prior to S/N 94G05600-021 & Below
02s447	Condensing Unit 1/3 hp 115-V R-134a	1			1			Used on S/N 94G05600-021 & Up
02s433	Condensing Unit 1/2 hp 115-V R-134a		1			1		Used on S/N 94A00059 & Up
02s428	Compressor 3/4 hp 115-V R-134a			1			1	Used on S/N 94A00094-023 & Up
03s176	Light Switch	1	1	1	1	1	1	
03s286	Power Switch 115-Volt	1	1	1	1	1	1	
04s023	Temperature Control	1	1	1	1	1	1	
05s275-1	Torque Rod	1	2	3	1	2	3	Used 12/86 & Before - 5/16" X 31-1/2"L
05s275-2	Torque Rod	1	2	3	1	2	3	Used 1/87 thru 9/91 - 7/16" X 35-5/8"L
05s275	Torque Rod	1	2	3	1	2	3	Used 9/91 and after - Square 28-1/2"L
05s276	Torque Wrench	2	2	2	2	2	2	Use to Adjust Tension on Door
05s277	Torque Pin	1	2	3	1	2	3	Holds the tension on the Torque Rod
XXXXX	Threaded Top Mounting Bracket & Hinge Pin	1	2	3	1	2	3	Used on 95C01927-395 and Above
05s322	Top Mounting Bracket	1	2	3	1	2	3	Left Hand Hinged
05s280	Top Hinge Pin	1	2	3	1	2	3	2-1/2" Long - Goes into Top of Door
05s279	Top Hinge Bushing	1	2	3	1	2	3	Black - Fits over Above Pin
05s281	Top Hinge Clip	1	2	3	1	2	3	Aluminum
30s362	Door Socket - L.H.	1	2	3	1	2	3	Door Sets in it
05s247	Groove Pin for Above	2	4	6	2	4	6	Keeps Door Socket From Moving
05s324	Hold Open Arm - L.H.	1	2	3	1	2	3	
05s371	Pin For Hold Open Arm	1	2	3	1	2	3	Holds Arm to Channel
12s077	Washer	1	2	3	1	2	3	Hold Open Arm to Door
05s442	Cotter Pin	1	2	3	1	2	3	Hold Open Arm to Door
12s206	Lock Nut	1	2	3	1	2	3	Hold Open Arm to Door (old way to do it)
29s352	Top Hinge Cover	1	2	3	1	2	3	Covers Top Hinge Screw Holes
05s433	Dial Thermometer	1	1	1	1	1	1	
05s408-1	Gasket Retainers		2	3		2	3	Black - Set of 4
05s408-2	Gasket Retainers	1			1			Black - Set of 4
18s255	Magnetic Door Gasket	1			1			
18s228	Magnetic Door Gasket		2	3		2	3	
06s010	Flourescent Lamp		1	2		1	2	
06s073	Flourescent Lamp	1			1			
06s046	Ballast	1			1			
06s016	Ballast		1			1		
06s123	Ballast			1			1	
06s004	Lamp Holder		2	4		2	4	
06s019	Starter	1			1			
06s024	Starter Socket	1			1			
06s074-1	Plastic Lamp Sleeve with End Caps	1			1			
06s074-2	Plastic Lamp Sleeve with End Caps		1	2		1	2	
06s044	Lamp Holder Bottom	1			1			
06s045	Lamp Holder Top	1			1			
17s362	Drier (Sweat)	1	1	1	1	1	1	Used on 92H04508-368 & Up
18s063	Drain Hose	5 ft.	5 ft.	5 ft.	5 ft.	5 ft.	5 ft.	
19s532-4	Door Jamb Heater		1	1		1	1	
19s532-5	Door Jamb Heater		1	1		1	1	
19s532-6	Door Jamb Heater			1			1	
19s614-2	Door Jamb Heater	1			1			

PART NOS.	DESCRIPTION	UMM 1-BS	UMM 2-BS	UMM 3-BS	UMM 1-TS	UMM 2-TS	UMM 3-TS	NOTES
19s465	Female Plug	1	2	3	1	2	3	
19s216	Power Cord	1	1		2	2	1	For 115-Volt and Condensate Pan
19s580	SJ Cord and Anti Sweat Heater		2	3		2	3	For Anthony Door Frame(S)
19s663	SJ Cord and Anti Sweat Heater	1			1			For Anthony Door Frame
19s473	Condensate Pan Heater				1	1	1	
20s094	Service Valve		1	1		1	1	
20s107	Overload			1			1	for 2-S-119 R-12 Compressor
20s118	Overload		1			1		for 2-S-129 R-12 Compressor
20s098	Relay			1			1	for 2-S-119 R-12 Compressor
20s119	Relay		1			1		for 2-S-129 R-12 Compressor
20s100	Start Capacitor			1			1	for 2-S-119 R-12 Compressor
20s121	Capacitor		1			1		for 2-S-129 R-12 Compressor
20s122	Capacitor / Relay Assembly		1			1		for 2-S-129 R-12 Compressor
21s007	Condenser Motor Bracket		1	2		1	2	
21s015	Condenser Fan Blade		1			1		
21s017	Condenser Fan Blade			2			2	
21s072	Condenser Fan Motor		1	2		1	2	
21s148	Evaporator Fan Motor	2	2	3	2	2	3	
21s080	Evaporator Fan Blade	2	2	3	2	2	3	
76218	Evaporator Fan Bracket	2	2	3	2	2	3	
22s172	Upper Cantilever Shelf	4			4			
22s171	Lower Bottom Wire Rack	1			1			
22s268	Upper Cantilever Shelf		8	12		8	12	See Price List #1318 HGL/M Section
22s128	Lower Bottom Wire Rack		2	3		2	3	
22s169	Flue Spacer	1			1			White Wire
22s121	Flue Spacer		2	3		2	3	
93169	Upright Shelf Post	2	3	6	2	3	6	
25s040	Condenser Coil Only		1			1		
25s041	Condenser Shroud		1			1		
25s050	Condenser Coil Only			1			1	
25s055	Condenser Shroud			1			1	
26s100	Evaporator Coil	1			1			
26s074-1	Evaporator Coil		1			1		
26s074-2	Evaporator Coil			1			1	
29s427	Anthony Door - L.H. Hinged	1			1			Silver - High Polish Trim
29s337	Anthony Door - L.H. Hinged		2	3		2	3	Silver - High Polish Trim
30S354	Aluminum Trim Upper	1			1			Silver - Holds Top Panel
30S355	Aluminum Trim Lower	1			1			Silver - Holds Top Panel
30S488-1	Aluminum Trim Lower		1			1		Silver - Holds Top Panel
30S489-1	Aluminum Trim Upper		1			1		Silver - Holds Top Panel
30S488-2	Aluminum Trim Lower			1			1	Silver - Holds Top Panel
30S489-2	Aluminum Trim Upper			1			1	Silver - Holds Top Panel
35S021	Leg Plate				4	4	6	
35S032	Legs				4	4	6	Six Inch
93963-2	Top Decorator Panel		1					Painted White 4-3/4" X 52"
93963-3	Top Decorator Panel			1				Painted White 4-3/4" X 77-5/8"
93963-1	Top Decorator Panel	1						Painted White 4-3/4" X 32-5/8"
93962-1	Top Decorator Panel				1			Painted White 11-1/4" X 32-5/8"
93962-2	Top Decorator Panel					1		Painted White 11-1/4" X 52"
93962-3	Top Decorator Panel						1	Painted White 11-1/4" X 77-5/8"
93165-1	Vertical Side Door Jamb	2	4	6	2	4	6	White Plastic
93165-2	Horizontal Top & Bottom Door Jambs		4			4		White Plastic

PART NOS.	DESCRIPTION	UMM 1-BS	UMM 2-BS	UMM 3-BS	UMM 1-TS	UMM 2-TS	UMM 3-TS	NOTES
93165-3	Horizontal Top & Bottom Door Jambs			6			6	White Plastic
93776-2	Horizontal Bottom Door Jamb	1			1			White Plastic
93776-1	Horizontal Top Door Jamb	1			1			White Plastic
93569	Pullout Coil Assembly R-12			1				Used on S/N 92H04508 & Below
93559	Pullout Coil Assembly R-12		1					Used on S/N 92H04508 & Below
93844	Pullout Coil Assembly R-12	1						Used on S/N 92H04508 & Below
90450-1	Heat Exchanger R-12						1	Used on S/N 92H04508 & Below
93201	Heat Exchanger R-12					1		Used on S/N 92H04508 & Below
93843	Heat Exchanger R-12				1			Used on S/N 92H04508 & Below
94318	Pullout Coil Assembly R-12			1				Used on S/N 92H04508 Thru 94A00094
94312	Pullout Coil Assembly R-12		1					Used on S/N 92H04508 Thru 94A00059
94308	Pullout Coil Assembly R-12	1						Used on S/N 92H04508 Thru 94G05600
94320	Heat Exchanger R-12						1	Used on S/N 92H04508 Thru 94A00094
94315	Heat Exchanger R-12					1		Used on S/N 92H04508 Thru 94A00059
94310	Heat Exchanger R-12 & R-134a				1			Used on S/N 92H04508 and Up
94394	Pullout Coil Assembly R-134a			1				Used on S/N 94A00094 and Up
94377	Pullout Coil Assembly R-134a		1					Used on S/N 94A00059 and Up
94158	Pullout Coil Assembly R-134a	1						Used on S/N 94G05600 and Up
94411	Heat Exchanger R-134a						1	Used on S/N 94A00094 and Up
94396	Heat Exchanger R-134a					1		Used on S/N 94A00059 and Up
93362	Evaporator Coil Cover		1			1		White Metal
92916	Evaporator Coil Cover			1			1	White Metal
93781	Evaporator Coil Cover	1			1			White Metal
93793	Access Panel	1						White - Covers Compressor Area
93537-1	Access Panel		1					White - Covers Compressor Area
93537-2	Access Panel			1				White - Covers Compressor Area
93856	Water Pan Assembly	1	1	1				Next to Compressor
90638	Condensate Pan Assembly Complete				1	1	1	Underneath Case
93088	Condensate Pan Only				1	1	1	Underneath Case
92943	Shell End Extensions				2	2	2	Top Side Ends - Painted White
93883	Hot Gas and Plate Assy.	1	1	1				