


corresponding changes, improvements, additions or replacements for equipment previously sold or shipped.

Item Part #	Description	Wiring Item #	Item	Part #	Description	Wiring Item #	
Fan Assemblies an	ND THERMOSTATS		Неат	ERS			
A. 6W Fan Asse	embly	(1)	C.		Canopy Anti-Sweat	Heater (3)	
0058698	Fan Motor, Evapor	ator		NA	4 ft		
0142780	Fan Blade			0109417	6 ft		
	embossing toward r	notor		0109417	8 ft		
	6			0109418	12 ft		
B. 0137880	Optional Adjustab	le (2)					
	Refrigeration Thermostat		LAMPS AND BALLASTS				
	e		D.		Ballast, Electronic	(4)	
				0428648	2 lamps		
				0428649	3 lamps		
				0428650	4 lamps		
			E.		Fluorescent Lamp	(5)	
Noto: Changes are	NOT underlined				Replace with like fixtu	()	
Note: Changes are		t hostor (norso 1					
	the canopy anti-swea						
	ft and 6-ft data (page	S 1, 2, 3 & 4); allu					
updated wiring dia	•	a					
Revision B returne	d the correct data to p	age 3.					

Revision C returned the correct data to page 1.

Engineering Plan Views

Dimensions shown as inches and (mm).




Front

	4 ft	6 ft	8 ft	12 ft	
General					
(A) Case Length (without ends or partitions)	48 1/4 (1226)	72 3/8 (1838)	96 3/8 (2448)	144 1/2 (3670)	
(Each end and insulated partition adds $1^{1/2}$ in. (38 mm) to case lin	e up.)				
Maximum O/S dimension of case					
back to front (includes bumper)	46 1/2 (1182)	46 1/2 (1182)	46 1/2 (1182)	46 1/2 (1182)	
Back of case to front of splashguard	38 7/8 (986)	38 7/8 (986)	38 7/8 (986)	38 7/8 (986)	
Back of case to O/S edge of front skid rail	29 1/4 (743)	29 1/4 (743)	29 1/4 (743)	29 1/4 (743)	
Width of skid rail	4 1/2 (114)	4 1/2 (114)	4 1/2 (114)	4 1/2 (114)	
RH end of case to outside edge of external support	5 1/2 (140)	5 1/2 (140)	5 1/2 (140)	5 1/2 (140)	
Distance between edges of external and center supports	NA	31 1/8 (790)	40 5/8 (1032)	40 5/8 (1032)	
Distance between edges of center supports	41 1/4 (1048)	NA	NA	44 (1118)	
Stub-up area between front skid rail and splashguard	7 3/4 (199)	7 3/4 (199)	7 3/4 (199)	7 3/4 (199)	
Electrical Service (Electrical Field Wiring connection	n point)				
(B) RH End of case to center of farthest knockout	38 1/4 (972)	64 ³ /8 (1635)	88 3/8 (2245)	136 1/2 (3467)	
Back O/S of case to center of knockout	34 5/8 (881)	34 5/8 (881)	34 5/8 (881)	34 5/8 (881)	
Length of electrical raceway	16 1/8 (410)	34 1/2 (876)	35 5/8 (903)	35 5/8 (903)	
Waste Outlet 🛛 🖲					
(C) RH End of case to the center of waste outlet	24 1/8 (613)	24 1/8 (613)	24 1/8 (613)	72 1/4 (1835)	
LH End of case to the center of waste outlet	24 1/8 (613)	48 1/4 (1226)	72 1/4 (1835)	72 1/4 (1835)	
Water Seal					
Edge of water seal to center of waste outlet	4 (102)	4 (102)	4 (102)	4 (102)	
Outside diameter of the drip pipe	1 1/2 (38)	1 1/2 (38)	1 1/2 (38)	1 1/2 (38)	
Note: Water seal outlet must clear front skid rail.					
Refrigeration Outlet					
Back of case to center of refrigeration outlet	30 5/8 (778)	30 5/8 (778)	30 5/8 (778)	30 5/8 (778)	
(D) RH end of case to center of refrigeration outlet	9 (230)	9 (230)	9 (230)	9 (230)	

2 of 8

C2-XGEP Technical Data Sheet

Dimensions shown as inches and (mm).



NSF Certification

These merchandisers are manufactured to meet ANSI /National Sanitation Foundation (NSF®) Standard #7 requirements.

Impact C2-XGEP Dairy / Delicatessen Precut & Packaged Produce

REFRIGERATION DATA

Note: This data is based on store temperature and humidity that does not exceed 75° F and 55% R.H.

C2-XGEP	Unlit	Lit		
Discharge Air (°F)	32	30		
Evaporator (°F)	28	26		
Unit Sizing (°F)	26	24		
Btu/hr/ft*	Unlit	Lit		
Parallel 725 825				
Conventional 755 860				
*For all refrigeration equipment other than				
Hussmann, use conventional Btu values.				

DEFROST DATA

	C2-XGEP
Frequency (hr)	12
Defrost Water (lb/ft/day)	6
(± 15% based on case configura	tion and
product loading).	
0 T	CA MODD

OffTime	C2-XGEP
Time (minutes)	30

ELECTRIC OR GAS Not Recommended

CONVENTIONAL CONTROLS Low Pressure Backup Control

	C2-XGEP
CI/CO**	19°F/9°F

Indoor Unit Only, Pressure Defrost Termination** 48°F **Use a Temperature Pressure Chart to determine PSIG conversions.

PHYSICAL DATA

Merchandiser Drip Pipe (in.)	1 ¹ /2
Merchandiser Liquid Line (in.)	3/8
Merchandiser Suction Line (in.)	7/8

Estimated Charge (lb)***


4 ft	1.6
6 ft	2.3
8 ft	3.2
12 ft	4.5
***This is an average for all 1	refrigerant types.
Actual refrigerant charge may	vary by
approximately half a pound.	

Impact **C2-XGEP** Dairy / Delicatessen Precut & Packaged Produce

Electrical Data

			4 ft	6 ft	8 ft	12 ft				
Number of Fans—6W		1	2	2	3					
			Amperes			Watts				
			4 ft	6 ft	8 ft	12 ft	4 ft	6 ft	8 ft	12 ft
Evapora	tor Fan									
120V	60Hz	Standard	0.50	1.00	1.00	1.50	39	78	78	117
120V	50Hz	Standard	0.55	1.10	1.10	1.65	42	84	84	126
230V	60Hz	Export	0.25	0.50	0.50	0.75	40	80	80	120
230V	50Hz	Export	0.28	0.56	0.56	0.84	44	88	88	132
120V	60Hz	Energy Efficient	0.26	0.52	0.52	0.78	18	36	36	54
230V	60Hz	Energy Efficient	NA							
Canopy A	Anti-swe	at Heaters	NA	0.75	0.75	1.00	45	90	90	120
Minimur	n Circui	t Ampacity								
120V	60Hz	Standard	0.70	1.95	1.95	2.70				
120V	50Hz	Standard	0.75	2.05	2.05	2.85				
230V	60Hz	Export	0.45	1.45	1.45	1.95				
230V	50Hz	Export	0.48	1.51	1.51	2.04				
120V	60Hz	Energy Efficient	0.46	1.47	1.47	1.98				
230V	60Hz	Energy Efficient	NA							
Maximum Over Current Protection 120V		20	20	20	20					
		urrent Protection 230V	15	15	15	15				
Standard	l Lightin	g								
	Canopy	8	0.26	0.51	0.51	0.77	30	59	59	85
Optional	Lighting	g								
Additio	onal 1 Ro	w Canopy	0.26	0.51	0.51	0.77	30	59	59	85
		w Canopy	0.51	1.02	1.02	1.54	59	118	118	170
1 Row Rail Light		0.26	0.51	0.51	0.77	30	59	59	85	
1 Row Ledge Light		0.26	0.51	0.51	0.77	30	59	59	85	
Optional Shelf Lighting										
1 Row	Shelf Re	ceptacle	0.26	0.51	0.51	0.77	30	59	59	85
2 Row Shelf Receptacle		0.51	1.02	1.02	1.53	59	118	118	177	

115V Lighting Circuit Total = Standard Lighting + Total Optional Lighting + Optional Shelf Lighting 230V Lighting Circuit Total = Multiply 115V Lighting Circuit Total by 0.52



WARNING

All components must have mechanical ground, and the merchandiser must be grounded.

CIRCLED NUMBERS = PARTS LIST ITEM NUMBERS


Grayed components in 12 foot models only.

R = Red Y = Yellow G = Green BL = Blue B = Black W = White


• = 120V Power \bigcirc = 120V Neutral \equiv = Field Ground \overrightarrow{mm} = Case Ground

Light Circuits

Standard Lighting 1 Row Canopy or Optional 1 Row Rail



Optional Lighting 2 Rows Canopy



Note: Optional Construction for 2 Rows Canopy on the 8 ft would be to wire (1) 4-lamp ballast.

WARNING

All components must have mechanical ground, and the merchandiser must be grounded.

CIRCLED NUMBERS = PARTS LIST ITEM NUMBERS

Grayed components in 12 foot models only.

 $R = Red \quad Y = Yellow \quad G = Green \quad BL = Blue \quad B = Black \quad W = White$

• = 120V Power \bigcirc = 120V Neutral

Impact C2-XGEP Dairy / Delicatessen Precut & Packaged Produce

SHELF CONFIGURATION


This merchandiser is designed for two or three shelves.

The depth of the shelf used in the top eight (8) shelf hole locations is critical to case performance.

If a shelf is placed in one of the top eight (8) locations it must comply with the angle/depth requirements listed below.

Shelf Angle	Maximum Shelf Depth
0 °	12 in.
15 °	14 in. or less
30 °	18 in. or less
45 °	18 in. or less

NOTE: Shelves placed in the lower positions may be up to 18 in. deep when positioned at a 0 ° angle.



Impact **C2-XGEP** Dairy / Delicatessen Precut & Packaged Produce

The ballast for the canopy and shelf lamps is located behind the light tray on the left-hand end (when facing case) of the merchandiser.

To access the ballast:


- 1. Remove screws from the front-lip of light tray flange covering the bottom edge of the canopy. Also remove screws located near the middle-rear of light tray.
- 2. Swing front of light channel down on it's rear hinge.
- 3. Service or replace ballasts as required.
- 4. Reassemble items as they were originally installed. Make sure that wires are not pinched by re-installed light tray.

NOTE: Rail lamp ballast is located behind the lower front panel.

CANOPY ANTI-SWEAT HEATER

Foil-covered Anti-sweat Heater

The canopy anti-sweat heater location is shown below. Connections are in the Electrical wireway.



Light Tray